







### **APPLICATIONS**

- Product designed to prevent odors and organic blockage in pipes and vats of fat.
- Recommended for public areas and industries where grease continually causes blockage and bad smells: restaurants, hotels, residences, and in the food industry.

#### **HOW TO USE**

**Pipes:** Dilute the dose in 2-3 liters of water to make it easy to apply. Apply to problem sinks at night after business hours to allow it to work for a longer period of time.

Allow it time to work and then begin using the facilities normally.

**Fat vats:** Dilute the dose in water to make it easy to apply. Add the dose near the equipment or apply it directly to it.

#### DOSAGE

**Pipes:** For treating organic blockages in pipes, apply 10 ml of product per meter of pipe.

**Fat vats:** Apply 1 liter of product per 1,000 liters of volume to be treated Treat on a daily basis at first.

Apply product daily at the end of the day for maximum effectiveness. When the problem is under control, reduce the frequency of applications (weekly).

# With active microorganisms

## **BENEFITS**

- Highly powerful: prevents clogging and eliminates odors, empty septic tanks less often, and prevents the facilities from deteriorating
- ✓ Biological action: highly active due to its microorganisms and enzymes
- Safe to use: non-corrosive product
- Environmental improvement: eco-design product, minimizes its environmental impact, due to its biological action, it preliminarily breaks down organic matter
- Other benefits: especially suitable for problems with fats and oils in the food industry

FOOD INDUSTRY. WINERIES. FRUIT AND VEGETABLE SHOPS. ENVIRONMENTAL INDUSTRY.